




## Terrasoft® Edge cover




Existing components are enhanced by the Terrasoft edge covers. You will experience a visual enhancement and an additional benefit in the form of seating area. The Terrasoft Edge Cover consists of pure rubber granules and is bound and coated with polyurethane. In addition to the insulating properties of the edging, the covering is heavy and has a high positional security. The height of 50 mm also compensates for minor unevenness caused, for example, by the natural aging process of walls and wall projections. The edging can be used to quickly and easily renovate existing walls. The new wall seal is weather-resistant and very easy to keep clean.

### ADVANTAGES

- fast and easy renovation of wall endings
- high positional security due to its own dead weight
- insulating effect
- very stable

### APPLICATION

The Terrasoft edge covering also serves as an outdoor wall protection cover in the environment of playground equipment as well as edge protection e.g. at sand boxes.



Subsequent covering of wall endings: The edge covering is glued onto firm existing edgings.

## INSTALLATION INSTRUCTIONS

Terrasoft Edge cover elements are subsequently spot glued in accordance with our gluing instructions on firm edges made of e.g. wood or concrete.

Mite cuts can be produced without problems due to the flat simple shape of the elements with on-site adjustment using a compass or table saw.

### Preparation of the subsoil:

Make sure that the adhesive surfaces are free of oil, grease and other residues, e.g. paint, rubber abrasion particles, etc. Now place the element on the prepared surface according to the installation plan.

### Notes to selective gluing:

Pierce the membrane in the threaded part of the adhesive cartridge and screw on the cut plastic nozzle. Using a screwdriver, remove the bottom plate of the cartridge and insert it into the manual or pneumatic gun.

The bonding takes place on the completely cleaned underground by means of adhesive dots on the bottom of the Edge cover.

The surface and ambient temperature must be at least 5 ° C. The panels should only be glued in dry weather. Adhesive cartridges must not be stored below 10 ° C.

Please follow the care instructions.

### Colours



-10x redbrown  
-12x green  
-13x anthracite

### Specifications



### Spart parts



4525001x1  
Gluing

## SURFACE ADHESION

The surface adhesion is mainly for the fixation of solid rubber products.

### Preparation of the subsoil

The concrete foundation must be rough, clean and dry. Please pay attention that the glueing areas are free of oil, greases and other residues e.g. colours, rubber abrasion, cement mist etc.

The surface and environment temperature must be at least 8°C resp. at least 3°C above the dew point temperature. Air temperature not higher than 80%.

### Adhesion priming

Fill adhesion priming in another pot and apply thinly on the subsoil by rolling or painting.

If necessary, subsequently smooth put to avoid puddles.

The drying depends on the air humidity.

With a high air humidity the drying is delayed. In the drying time, a direct water admission should be avoided.


Under certain circumstances, it may be necessary to grind the dried adhesion priming. The grinding dust should be removed thoroughly.

### Glueing process


Admit 1.5 kg hardener to 10 kg glueing and mix it at a low rotative speed achieving a mass free of mist.

When glueing rubber on concrete, the glueing mass should be applied and compressed on the concrete surface with a toothed spatula (4 mm).

Please pay attention that the area is not stepped on for 48 hours.



adhesion priming



glueing process

## JOINT FILLER

The joint filler is applied when already laid elements should be glued together upon the impact edges. This way, it is not possible to take away single elements.

### Processing

With the supplied plastic nozzle, an exact dosage is achieved by simply pressing the middle of the bottle.

Please pay attention that the joint filler remains liquid during the processing period. The joint should not be larger than 3 mm.

Please pay attention that the surface is not stepped on for 48 hours.

## CARE INSTRUCTIONS

A regular care of the layed slabs serves the security and increases its attractive appearance and the life span.

- The dust on Terrasoft areas can be swept off with a broom with hard bristles. The can also be cleaned with a high-pressure cleaner. This also removes dirt residues from the porous surface of the slabs.
- Depending on the degree of soiling, a deep cleaning, e.g. be carried out with a high-pressure cleaner.
- Coloured surfaces can be subsequently refined through application of a special spray coating. In the case of EPDM paving slabs, aggressive soiling due to environmental influences can be removed by sanding down the surface.
- Fouling with moss or grass in the joint area can lead to the panels being pushed apart or pushed up. Be sure to remove such growth early.
- Decolorations of the surface can occur through durable remaining ram moisture on the substrates as well as diverse plants in the direct surroundings of the slabs.
- External influences can have an effect on the condition of the surfaces. Weather, UV radiation, dust from the air, sites near the coast with high salinity or sand areas near the impact protection slabs can have a negative effect on lack of care.
- In cases of abrasion slabs have to be replaced